



Initial Cleaning

Once all panels and joints are installed, remove the protective film and clean all surfaces down with an anti-static solution, or anti-static wipes. This is required as the panel may have static build up, and any dust in the atmosphere will adhere to the surface of the panel.

Regular Cleaning

- Altro Whiterock can be cleaned with a diluted soap/detergent solution, such as AltroClean 44.
- When cleaning the Whiterock surface, we recommend the temperature of water does not exceed 140°F (60°C).
- Pressure cleaning with hot water may be used with the pressure nozzle, a minimum of 2 feet (600mm) away from the surface.
- To reduce the buildup of static, cleaning the panels with an anti-static solution is recommended.
- For stubborn stains use AltroClean 44 cleaner or equivalent alkaline cleaner.
- Some cleaning agents may adversely affect Altro Whiterock.
- Do not use materials containing abrasives or solvents.

Cleaning Agents

Anti-static solutions* can be obtained from a variety of cleaning product manufacturers. Example suppliers are:

S.C. Johnson	800.558.2332
Hillyard's Inc.	800.365.1555

* Some anti-static solutions for floors can also be used on Altro Walls. Consult your Altro representative before using.